
PRODUCT CARE

- Stains should be treated promptly to avoid permanent damage to the fabrics used for Pakumi wraps. Should staining occur, please use spot cleaning method or dry clean with a professional dry cleaner.
- As with any spot cleaning method, be sure to test your detergent in a controlled area before proceeding. Then, using as little detergent and water as possible, gently clean the fabric or stained area. Lay flat to dry. Do not wring.
- Please be aware that machine washing and drying may cause shrinkage.
- Lint and light dirt, if it collects on the felt buttons, may be removed by dabbing the area with masking tape.
- IRON WRAP™: Pakumi wraps are made with temperature sensitive fabrics. Please allow enough time for curling and flat irons to cool completely before placing in the Iron Wrap accessory.
- DRYER WRAP™: Pakumi wraps are made with temperature sensitive fabrics. Please allow enough time for hair dryers to cool completely before placing in the Dryer Wrap accessory.

